


Starter Guide

MB Warmer

Take along, reheat, enjoy!

Refer to the MB Warmer manual for additional information.



Almost mealtime?

Open the silicone tab of your MB Warmer.

To plug your MB Warmer, you have 2 options:

- AC outlet
- 12V* car outlet

To open the jack protector, hold the top of the protector with your thumb and open it with your index finger.



Turn the MB Warmer on and choose one of the 3 heating programs.

Follow our recommendations p. 17 !

Watch the magic happen!

A little setback? Leave your MB Warmer on and its content will be kept warm for 1h.



It's ready: bon appétit !
Be careful, it's hot!

Once unplugged and cooled, close the jack protector, and clean your bento box!

Refer to p. 16 to discover our maintenance instructions.



The MB Warmer is ready to follow you on your next adventure!